Our AERO® Carpet & Upholstery Cleaners compose a complete line for a carpet care professional. It includes concentrates for extraction, bonnet, and rotary cleaning, as well as a series of spotters and carpet protectants.

HIGHLIGHTS

- Heavy duty for extremely soiled carpets
- Excellent extraction and bonnet cleaner
- Leaves a pleasant fresh scent

TYPICAL PROPERTIES

- Specific Gravity: 1.1
- pH: 12.5
- Total Alkalinity (as Na₂O):
- 4.2%
- Appearance: Light blue liquid
- Odor: Pleasant

SAFETY CAUTIONS

- Keep out of reach of children.
- It is recommended that protective gloves and safety glasses be worn when using this product.
- Refer to M.S.D.S. for additional safety information.

HMIS RATINGS

Flammability





Vapor Rug

Heavy Duty Rug & Carpet Shampoo Formulated For Older, Easily Soiled Carpets

- Hot Water Extraction Cleaning Bonnet Cleaning
- Traffic Lane Pre-Spotting

A highly concentrated, heavy duty alkaline carpet cleaner that is specifically formulated to remove grease, oil and soil from older, easily soiled carpets. Formulated with synthetic wetting agents, solvents, water softeners, optical brighteners, and anti-foaming agents. Leaves a nice fresh scent.

DIRECTIONS: Do not use on stain-resistant carpets. **Hot Water Extraction:** Dilute 1 ounce to each gallon of water in the solution tank. For heavily soiled carpets use 2 oz./gal. For hard water use the dilution chart below.

Water Hardness	
ppm	grains
0-150	0-9
150-250	9-14.5
250-350	15-20.5
350-450	20.5-26
	ppm 0-150 150-250 250-350

If the value of water hardness is unknown, start with 1 oz./gal. and check the solution for clarity. If slightly cloudy, add enough concentrate to clear the solution. For traffic lane pre-spotting, use 2 ounces per gallon. Bonnet Cleaning: Although this product has been formulated specifically for steam extraction, it is also a good bonnet cleaner when used in accordance with the directions below. Dilute as above, and spray approximately 100 sq. ft. at a time, holding sprayer 12" to 16" above carpet. Avoid soaking carpet. Dampen bonnet pad with water, do not soak. Spray bonnet with cleaning solution and place bonnet under machine on carpet, sprayed-side down. Buff carpet over sprayed area, turning the pad over or changing it when heavily soiled. Allow carpet to dry for 30 minutes to an hour, then vacuum thoroughly.

NOTE - If furniture must be replaced before carpet is dried, place cardboard strips under furniture legs.

distributed by:

